

# Linksys PAP2T Installation

Freitag, 3. August 2018 11:24



## Voice Response Menu

pap2t\_user

\*\*\*\* eingeben  
"Configuration menu. Please..."

100#	Check DHCP aktiv
101#	1 Enable DHCP
110#	Check DHCP Address
73738#	Factory Reset > 1 to confirm
7932#	1 Enable Web-GUI

## Regional

<b>Ring and Call Waiting Tone Spec</b>	Ring Waveform: <b>Sinusoid</b>	Ring Frequency: 20
	Ring Voltage: 85	CWT Frequency: 440@-10
	Synchronized Ring: no	

## User

<b>Ring Settings</b>	Default Ring: 1	Default CWT: 1
	Hold Reminder Ring: 8	Call Back Ring: 7
	Cfwd Ring Splash Len: 0	Cblk Ring Splash Len: 0
	VMWI Ring Splash Len: <b>0.5</b>	
	VMWI Ring Policy: New VM Available	
	Ring On No New VM: no	

## Line

<b>Proxy and Registration</b>	Proxy: <b>raspbx.local.mesh:5160</b>	Use Outbound Proxy: no
	Outbound Proxy:	Use OB Proxy In Dialog: yes
	Register: yes	Make Call Without Reg: no
	Register Expires: 3600	Ans Call Without Reg: no
	Use DNS SRV: no	DNS SRV Auto Prefix: no
	Proxy Fallback Intvl: 3600	Proxy Redundancy Method: Normal
	Voice Mail Server:	Mailbox Subscribe Expires: 2147483647
<b>Subscriber Information</b>	Display Name: <b>Ost</b>	User ID: <b>678</b>
	Password: <b>notfunk</b>	Use Auth ID: yes
	Auth ID: <b>678</b>	
	Mini Certificate:	
	SRTP Private Key:	